





Bezeichnete Tastenstellung: MW gedrückt

Jazz	Solo	UKW	K	V8	PA	L	TA	TB	AUS
				M					

Sprache	Bass	Stereo
---------	------	--------



Leerkontakte



8+1/12-Kreis-Super

**6/634**  
Stereo

Steuergerät 3004, Arabella,  
Tannhäuser


- 0,125W
- 0,25W
- 0,33W
- 0,5W
- 1W
- Widerstands-sicherung 5W

V20	V21	V22	V23
179.857.15	179.857.15	179.857.15	179.857.15

V20	V29	V44	V45
179.857.15	179.857.15	179.857.15	179.857.15

C184, C185, L111, L112, L113, L114, L109, L110  
nur bei Tannhäuser



Alle Buchsen u. Fassungen von der Einsteckseite gesehen  
Alle Stecker u. Röhren von der Stiftseite gesehen

Bandfilter- und Spulen-Anschlüsse, Ansicht  
Kaschierungsseite

